

CANgas

The disposable, portable gas canisters for small quantities



Messer is the world's largest privately owned specialist for industrial, medical and specialty gases and has a large number of high purity gases and gas mixtures in its conventional gas cylinder program, generally provided in 10 or 50-liter cylinders.

For many tests or measurements, however, gases are only required in small quantities, leaving the residual gas in such large cylinders unused.

A heavy steel cylinder is not always necessary for testing sensors in explosion areas or for monitoring ambient air. All that is needed is a small and light gas canister.

Likewise, for special applications in research and development, often only a small amount of a certain gas or gas mixture is required. For this purpose, Messer offers gas canisters in various sizes that are easy to use.

An extensive equipment portfolio is available for the safe withdrawal and application of gases or gas mixtures from disposable canisters.



Fully automated filling of pressure cans in Lenzburg

Small, light and flexible

CANgas canisters are small, light, handy and can be stored almost anywhere. The handling of gas canisters is extremely simple and only the required amount of gas is provided. This is environmentally friendly and the compact design saves space.



Blood gas analysis



Car exhaust emission testing

Gas canister

All gas canisters offered by Messer are made of aluminum. Aluminum is light and compatible with all common components, especially reactive ones.

Applications

Gas canisters are used wherever small quantities are required for sporadic or mobile use, making conventional refillable gas cylinders impractical. Disposable canisters are small, light and handy.

Test gases are used, for example, for testing sensors which monitor the threshold values of toxic and flammable gases in potentially hazardous areas or which raise the alarm when environmentally hazardous substances are released. The sensors are usually tested on site using an appropriate test gas.

In analytics, e.g. the automobile exhaust emission control (Lambda gas mixture) or the blood gas analysis, operating and calibration gases in gas canisters are also used when only small quantities are required.

Gas canisters also provide advantages in research and development if low volumes are needed.



CANgas Aerosol Canisters

Aerosol canisters are particularly lightweight and easy to handle. They are suitable for up to 12 liters (gas content) of non-toxic and non-corrosive pure gases or gas mixtures.

Aerosol canisters have a built-in shut-off valve and are equipped with an 7/16" 28 UNEF connection.

	Gas Canister 0.5 litre	Gas Canister 1 litre
Gas content	6.7 l	12 l
Geometric volume	0.56 l	1.0 l
Empty weight	approx. 80 g	approx. 113 g
Dimensions (height x diameter)	190 mm x 65 mm	260 mm x 75 mm
Filling pressure	12 bar	12 bar
Built-in shut-off valve	B188 – with 7/16" 28 UNEF Thread	
According to directive	Directive 75/324/EEC - aerosol dispensers	

Products

Messer provides an extensive range of pure gases and gas mixtures in different gas canisters.

Test gas mixtures are delivered with a certificate of conformity which can be found on the aluminum canister body label. It contains information on the exact composition, the tolerances and the stability of the gas mixture.

Depending on the gas mixture a certificate of analysis can also be supplied which provides more detailed information on the real value of the corresponding component and its uncertainty.

	CANgas Aerosol Canisters
Pure Gases e.g.: O ₂ , H ₂ , N ₂ , Ar, He, synth. air, HC (CH ₄ , C ₂ H ₆ , C ₂ H ₄ , C ₃ H ₈ , C ₃ H ₆), ...	x
Standard gas mixtures with non-corrosive components (1-/2- components in balance gas) e.g.: O ₂ in N ₂ ; CO ₂ in He; Ne in Ar; CO ₂ /O ₂ in N ₂ ; ...	x
Standard gas mixtures with corrosive components (1 component in balance gas) e.g.: H ₂ S in N ₂ ; NO in N ₂ ; NO ₂ in synth. air; ...	-
Standard gas mixtures with flammable components (1-/2- components in balance gas) e.g.: CO in N ₂ ; H ₂ in N ₂ ; CH ₄ in synth. air; C ₂ H ₂ in He; n-C ₄ H ₁₀ /CO ₂ in N ₂ ; ...	x
Multi component gas mixtures, e.g.	
• Lambda gas mixtures e.g.: C ₃ H ₈ /CO/CO ₂ /(O ₂) in N ₂	x
• QUAD gas mixtures e.g.: H ₂ S/CH ₄ /CO/O ₂ in N ₂	-

CANgas equipment

Special withdrawal systems are used for withdrawing the gases from the gas canisters. These can be screwed directly onto the built-in shut-off valve which is, thereby, opened.

The gas canister withdrawal have the same connection for all types of gases. Thanks to only a few different components, maximum flexibility of application can be achieved. The NPT 1/8" female thread on the outlet or the hose nozzle permits a wide variety of connections for further gas transfer.

For the use of **CANgas aerosol canisters** the following withdrawal fittings made of aluminum have been established:

The dosing valve is used if:

- pressure reduction is not necessary
- dosing only takes place for a short time (because of the falling primary pressure, constant discharge over a prolonged period is only possible with readjustment)
- the connected system can withstand a pressure of 12 bar, or is open to the atmosphere.

Due to its special construction the **TOP Valve** provides:

- evacuation up to the closed gas canister valve
- avoidance of contamination during withdrawal.

The pressure regulator reduces the output pressure to 0.6 bar (fixed factory setting). The flow rate can be adjusted with the integrated dosing valve. The pressure in the canister is indicated at all times on the primary pressure gauge.

This valve offers:

- exact dosing at reduced working pressure
- virtually constant discharge pressure with falling primary pressure
- limitation of the pressurization of the connected system (e.g. glass apparatus or measuring instrument).

Service and support

Every application has specific requirements concerning the gases and gas mixtures used and the optimal withdrawal systems. Many pure gases and mixtures as well as valves are available for immediate delivery from stock.

Whatever the conditions, we are glad to support you.

Further information

Special brochures are also available on the following topics:

- Specialty Gases
- High Purity Gases
- Gas Mixtures
- Helium
- Balloon Helium
- Specialty Gas Equipment
- Process Gases for Analytical Applications
- Environmental Analysis
- myLab.

Specialty gases - Website

For further information please also visit the specialty gases - website of the Messer Group.

You can easily reach the website via the link in the address or with the QR code shown here.



gasesforlife.de

CANgas: 03 / 2025



MESSER 
Gases for Life

Messer Schweiz AG

Seonerstrasse 75

5600 Lenzburg

Phone 062 886 41 41

info@messer.ch

<https://www.messer.ch>

<https://specialtygases.messergroup.com>